



Subscription and Activation Notice!

The AS WX 1 Satellite Weather Receiver requires a monthly subscription from XM WX Satellite Weather®. Before the AS WX 1 Satellite Weather Receiver can be used on the water, the subscription must be activated on your Humminbird® control head.



To activate XM WX Satellite Weather®:

1. The **XM Radio ID** is required to set up the XM WX subscription.
 - 1a. Use a Y-Cable to connect a GPS and the AS WX 1 Satellite Weather Receiver to your Humminbird® control head. The slots are keyed to prevent reversed installation, so be careful not to force the connectors into the slots.
 - 1b. Power on the control head and start Normal (with transducer attached) or Simulator mode (without transducer attached).
 - 1c. Press the MENU key twice to open the Main Menu. Select the Accessories tab. Highlight XM Weather, and press the RIGHT Cursor key. Select XM Info, and press the RIGHT Cursor key. The Radio ID is the set of uppercase, alphanumeric characters shown on the screen.

The XM Radio ID is the set of uppercase, alphanumeric characters shown under the XM Info menu, or on the receiver packaging, or on the bottom of the receiver.

Enter the XM Radio ID, and select NavWeather Basic Package.

NOTE: The Humminbird® control head must be powered **ON** with the receiver connected to complete the subscription activation process.

2. After you've noted the Radio ID, press the EXIT key to exit out of the Main Menu. Press the VIEW key until the Weather View is displayed. The Weather View is identified by the Signal Icon  on the screen.
3. Check the Signal Icon  to confirm that the unit is receiving a strong signal (4 bars). Move the receiver if the signal is weak. The most effective reception is outdoors, facing south, without any obstructions (i.e. people, trees, buildings), and at least 3 ft from the control head.
4. Contact XM on the web at www.xmradio.com and click Activate Radio, or call (800) 967-2346 or (800) 985-9200 to set up your account. Refer to your Radio ID, and select "NavWeather Basic Package."
5. The control head will begin to receive the authorization data.

NOTE: The control head must stay powered **ON** the full amount of time to complete the subscription activation process, which may take up to 1 hour. When activation is complete, the diagonal lines will disappear, and the Weather View will display current weather conditions on the chart. The XM Info menu will also display "NavWeather Authorized" when the activation status is confirmed. See the included manual for details.

XM WX Satellite Weather® Service Disclaimer

Hardware and required monthly subscription sold separately. Subscription fee is consumer only. Other fees and taxes, including a one-time activation fee may apply. All fees and weather data subject to change. XM WX Weather displays and individual product availability vary by hardware equipment. Reception of the XM signal may vary depending on location. Subscription subject to Customer Agreement included with the XM Welcome Kit and available at xmradio.com. Available only in the 48 contiguous United States. XM WX data is not available in Canada.

Contact Humminbird®

Contact our Customer Resource Center at **1-800-633-1468** or visit our web site at www.humminbird.com.